



## Service Bulletin

**SB** 00-6  
7-3-80

SUBJECT: NEW VEHICLE IDENTIFICATION NUMBER

VEHICLES: 1980 308 MODELS

SERIAL NO.: Starting with Serial No. 31309

REISSUE OF TECHNICAL INFORMATION NO. 361,  
DATED 2/14/80

### GENERAL INFORMATION

In compliance with Federal Regulation, FMVSS No. 115, 49 CFR 571.115, a new method of reporting the vehicle identification number has been adopted for the 1980 models.

The new number is made up of 17 digits which are subdivided into three sections. The new designations are attached.

EXAMPLE: 1980 U.S.A. V.I.N. = ZFFAA01A1A0021371

## 1980 VEHICLE IDENTIFICATION NUMBERS

The vehicle identification numbers are made up of 17 digits, subdivided into three sections.

Section I - made up of 3 digits assigned to Ferrari S.p.A.

- ZFF - code for Ferrari vehicles (GTB-GTS)
- ZDF - code for Dino vehicles (GT4)

Section II - made up of 6 digits

- #1 Digit - alphabetic letter to identify engine designation
  - A = Ferrari F 106 B 040 (8 cyl. - 3000cc Inject. USA M.Y. 80)
  - G = Ferrari F 106AE (8V-3000cc 78/79 USA - Japan version)

Example: USA V.I.N. = ZFFA

- #2 Digit - alphabetic letter to identify the safety system installed in vehicle
  - A = 3 point seat belts with automatic retractors

Example: USA V.I.N. = ZFFAA

- #3 & 4 digits - numbers to identify model designation  
Ferrari Models
  - 01 = F 106 AB (308GTBi)
  - 02 = F 106 AS (308GTSi)
  - 03 = F 106 AB (308GTB)
  - 04 = F 106 AS (308GTS)

Example: USA V.I.N. = ZFFAA01

- Dino Models
  - 01 = F-106 = AL/A (308GT4)

Example: USA V.I.N. = ZDFAA01

- #5 Digit - Alphabetic letter to identify market designation
  - A = LHD North America (USA)

Example: USA V.I.N. = ZFFAA01A

- #6 Digit - USA Check Digit (Prescribed by USA)
  - 1 = USA Version

Example: USA V.I.N. = ZFFAA01A1

Section III - made up of 8 letters and numbers

- #1 Letter - Model Year
  - A = USA 1980 M.Y. (Consecutive letters, i.e., B = 1981)

Example: USA V.I.N. = ZFFAA01A1A

- #2 Letter = Production Plant
- 0 = Maranello/MO (USA)

Example: USA V.I.N. = ZFFAA01A1A0

- #3 through #8 digits = Chassis Number

Example: USA V.I.N. = ZFFAA01A1A0021371

